Walla Sound

QUICK START GUIDE

See Instruction Manual for more Details

Use of Sport Earflap and Silicone Tips

Removal of silicone tips

Removal of sport earflap

Removal of sport earflap/silicone tips

The earflaps help during exercise to keep the earbuds in your ears.
For leisure use they can be removed if preferred.

Walla Sound

QUICK START GUIDE

See Instruction Manual for more Details

TOUCH MULTI FUNCTION BUTTON

Hold — Turn earbud on/off

2x — Accept: double press

2x — End: double press

Hold — Reject: hold 2 seconds

2x — Play/Pause: double press

Hold — Previous: left hold 1 seconds

Hold — Next: right hold 1 seconds

1x — Volume -: left short press

1x — Volume +: right short press

3x — Activating the voice assistant: triple press